

Husqvarna TS400F

Pièces de rechange

Spare parts

Ersatzteile

Piezas de repuesto

Ricambi

Onderdelen


Reservdelar

Peças sobresselentes

No.	Pos.	Description	No.	Pos.	Description
115 032 620	B	OM, TS350E, 8 languages	543 071 265		Sticker, Legs folding
115 032 720	B	IPL, TS350E, 8 languages	543 072 245		Sticker, "Risk of cut"
506 207 301	F	Water pump 230V, compl	543 074 336	C	Locking of bridle
506 207 302	F	Water pump 115 UK, compl	543 074 355	C	WASHER
506 577 501	E	Cable & connector	543 074 374	C	Spacer
540 064 601	D	COVER, PLASTIC	543 074 375	C	WASHER, D 10x30
540 064 701	D	UPPER HANDLE	543 074 382	C	Axle block TS400F
540 064 801	B	Material stop, table	543 074 386	C	Screw, Plunging screw
540 064 901	B	Table	543 074 393	B	Rubber carpet, extension
540 065 001	B	KIT TABLE	543 074 394	C	Mudflap, rear
540 065 101	C	SUPPORT SHEET, MUD FLAP REAR	543 074 433	C	Column
540 065 201	B	TABLE EXTENSION	543 074 439	A	Chain
540 065 301	C	ARM	543 075 105	F	Water dispenser 2
540 065 401	A	TANK ASSY	543 075 106	F	Water dispenser 1
540 065 501	D	MOTOR ASSY,SUPPORT	543 075 214	C	GAS SPRING
540 065 601	C	ARM POLE, UPPER	543 075 215	C	Screw, M8x50 ball and socket join
540 065 701	F	BLADE GUARD, FIXED	543 075 216	C	Handle, 45° M12, female
540 065 801	F	BLADE GUARD, COVER	543 075 217	A	REAR WHEELS
540 066 001	B	SLURRY COLLECTION	543 075 577	E	SWITCH 115V-25A
540 066 101	D	HANDLE	543 076 003	C	Spacer, ball bearing
540 066 201	D	Handle KIT, Completed	543 076 108	E	SUPPORT SWITCH
543 040 217	C	WASHER M20	543 080 759	D	LASER
543 043 323	B	SAFETY LOCKING	543 850 017	D	Nylon tie 5x250
543 043 357	D	Nut, Speed nut	543 850 036	C	Ruler, height adjustment
543 043 860	C	CRANK	543 850 045	E	SWITCH KEDU 400V
543 044 718	C-D	WASHER,20 (40x21x3)	543 850 047	B	Ruler, left
543 044 766	A-C	Nut, M8x125,Ballhead	543 850 049	B	Ruler, middle
543 044 864	A	Rivet	543 850 050	B	Ruler, right
543 044 897	C	WASHER, PVC, spacer	543 850 055	C	WASHER
543 045 004	C	Bearing, BALL BEARING 6004 2RS	543 850 055	C	WASHER
543 045 038	C	BEARING, needle bearing	543 850 072	C	WASHER
543 045 039	C	WASHER, BEARING	543 850 173	D	Flange, inner
543 045 131	F	SWITCH KEDU 230V	543 850 180	D-F	Motor 2,2 kW 230V EUROPE
543 045 136	E	Plug 400V Male	543 850 183	D-E	Motor 3 kW, 400V 3PHASES
543 045 145	E	Plug female 3P+N+T 16A 6H	543 850 195	D	Motor 2,2 kW 230V AUSTRALIA
543 045 146	E	Plug 110V Male	543 850 203	A	Feet pad
543 045 202	F	Rubber sealing	543 850 216	C	Indexable handle, nut M8
543 045 580	F	Hose 12x18	543 850 218	D	Sticker, "combined stop,ear manual"
543 045 654	D	HANDLE ANTIVIBRATION 25	543 850 283	D	Motor 1,5 kW 115V
543 045 738		Sticker, Using of pump	543 850 315		Sticker, WEEE
543 045 785		Sticker, Noise 96 dB	543 850 428	D	Bypass tee : pump 25W
543 045 900		Wrench 30 DIN 894	543 850 429	D	Filter with tube end
543 046 051	A	Plug, rubber 34D 28/34/30	543 850 455	D	Adaptator for filter
543 046 052	B	CAP, plastic D13	543 850 577	D	Hose 6x9
543 046 055	C	Cap GPN 1000/1077	544 948 701	B	Pivoting stop
543 046 084	F	Nut, wing M8 female	544 949 301	A	LEGS, FRONT SQUARE TUBE
543 046 090	B	NUT, wings	544 949 401	A	LEGS, REAR SQUARE TUBE
543 046 116	C	HANDLE, indexable M8, 48x80, female	722 781 803	D	Rivet, 3.2x6.7 alu
543 046 146	B	ANGULAR GUIDE,ALUMINIUM COUPE	722 794 302	A-C	ALU RIVET 4x10,3 Large head
543 046 205	A	SPRING, legs - tank	724 128 551	F	Screw crosshead M4x6
543 046 280	B	Rubber carpet, front	725 232 771	E	Screw, M5x10 hex FT
543 046 281	B	Rubber carpet, rear	725 237 071	C-D	Screw, M6x20 hex FT
543 046 300	B	ROLLER OF TABLE	725 237 671	D	Screw, M6x35 hex FT
543 046 574	A	FRONT WHEELS	725 244 971	B	Screw, M8x16 hex FT
543 046 647	A-D	WASHER 8.5X35.8X 3	725 245 171	C-D-E	Screw, M8x20 hex FT
543 046 660	D	WASHER L20, (Φ50-Φ21)X3	725 245 371	B	Screw, M8x25 hex FT
543 049 956	B	KIT ROLLER	725 245 571	B-C-D	Screw, M8x30 hex FT
543 069 972	A	Rail, water tank	725 245 771	B	Screw, M8x35 hex FT
543 069 974	E	tightenning sheet	725 246 351	B	Screw, M8x60 hex PT
543 071 264		Sticker, 45° position	725 246 471	F	Screw, M8x65 hex FT



No.	Pos.	Description	No.	Pos.	Description
725 249 171	C	Screw, M10x20 hex FT			
725 249 371	A	Screw, M10x25 hex FT			
725 250 551	A	Screw, M10x70 hex PT			
725 254 551	A	Screw, M12x65 hex PT			
725 528 901	D	SCREW, inhex M4x10			
725 544 501	A	Screw, Inhex M8X10			
725 546 201	A	Screw, inhex, M8x55			
727 645 351	C	Screw, sphere head M8x25			
728 736 205	C	Screw, set M6x8 inhex sharp end			
729 527 901	E	Screw, ST3.5x9.5 round PH			
729 534 601	A-F	Screw, ST4.2x19 round PH			
731 231 601	D	Nut, M6			
731 231 801	B-C-D-F	Nut, M8			
731 232 001	A	NUT M10			
731 432 201	A	Nut, M12,thin			
732 212 601	C	Nut, nyloc M20			
732 212 601	C	Nut, nyloc M20			
732 251 601	D	Nut, nyloc M6 PP325E			
732 251 801	A-B-C	Nut, nyloc M8			
732 252 001	A	LOCKNUT M10			
732 252 201	A	LOCKNUT M12			
734 113 601	D-F	WASHER, 4			
734 115 201	C-D	WASHER M6			
734 116 301	B-C-D	WASHER M8			
734 117 201	A-C	WASHER M10			
735 216 401	B-C-D	Washer ext, lock 8			
735 311 200	C	Locker clips, steel			
738 210 004	C	Bearing BALL BEARING 6000 2RS			

A




B

540 065 001




Compl *540 066 001

C




D




E


110 V (UK)




400 V (3 Phases)



F



230 V (EU)





www.husqvarnacp.com